

# PHYF214 PHYSICS LAB REPORT SEM1 2018-2019

## Lab 1 Group 7: Induction Impulse [I & II]

Ashwin Kumar K - 2017A8PS1034G

1<sup>st</sup> November, 2018

### 1 Experimental Tasks

Part A Determination of the induction voltage as a function

- of the strength of the magnetic field
- of the frequency of the magnetic field
- of the cross-section of the induction coil

Part B

- Measurement and evaluation of the induced voltage and the velocity of the falling magnet
- Calculation of the magnetic flux induced by the falling magnet as a function of the velocity of the magnet

### 2 Apparatus

Field coil, Induction coil of varying number of turns, digital multimeter, function generator, connecting wires, Forked light barrier, Glass Tube, Magnet, Coil, Connecting Wires.

### 3 Theory

The magnetic flux across a loop is expressed as  $\phi = \int B \cdot da$  where B is the magnetic field across the loop. If there is time variation of magnetic field and/or area of the loop there is induced voltage across the loop. The induced voltage E across a loop is given by  $E = -\frac{d\phi}{dt}$


## 4 Observations

### 4.1 Part A

The Least count of the Voltmeter is 0.001V.


The plot of Voltage in secondary coil (induction coil) and the current in the primary coil is shown below.

Magnetic Field strength (in mA)	Induced Voltage
10	0.054
15	0.083
20	0.12
25	0.149
30	0.189
35	0.208
40	0.241
45	0.27
50	0.307
55	0.333
60	0.366
65	0.4




Now let us plot the graph of Induced voltage v/s frequency of AC current in primary coil.

Magnetic Field frequency (kHz)	Induced Voltage
2.2	0.178
2.3	0.189
2.4	0.2
2.5	0.21
2.6	0.219
2.7	0.23
2.8	0.24
2.9	0.247
3	0.261




Now let us plot the graph between induced voltage and number of turns of the secondary coil (induction coil).

Number of turns	Induced Voltage	coil dia = 40mm
300	0.251	
200	0.164	
100	0.079	




Number of turns	Induced Voltage	coil dia = 25mm
300	0.101	
150	0.05	
75	0.027	

Number of turns vs Induced Voltage



Dia (in mm)	Area (in mm <sup>2</sup> )	Induced Voltage
40	1256.64	0.251
32	804.25	0.16
25	490.87	0.101


Number of turns vs Induced Voltage




**Analysis:** Now from the graphs give are very nearly linear which suggest that the the induced voltage in the secondary coil is proportional to the current in the primary coil, to the frequency of AC current in the primary coil, the number of turns in the secondary coil (induction coil) and also to its cross-section of the coil.


## 4.2 Part B

The length of the bar magnet is  $6\text{cm} = 0.06\text{m}$ . So for trial 1, the graph of the induced voltage is given below




And the graph of the flux will be integral of this, so for the lower peak and the higher peak the calculated flux is -0.0119 and 0.012 which approximately add up to 0.






The reading of the photo gate shows the time which magnet takes to pass through the coil and thus give us an approximate idea of the instantaneous speed while it entered the coil.





That shows the bar magnet crosses the photo gate in  $0.42 - 0.35 = 0.07$ s, which means that the velocity of the bar magnet at that instant is,  $v = 0.06\text{m}/0.07\text{s} = 0.85714 \text{ m/s}$  and at this velocity the upper peak of the induced voltage is 0.4V and we also observe that the later peak has greater magnitude then the preceding peak because velocity of the magnet while leaving the coil is greater as compared to that when entering the coil.

Similarly the data for the trial 2 is as follows.




the flux in this case is -0.012 and 0.012 which again approximately add up to 0.





The photo gate data shows velocity to be 0.667m/s done with the same calculation method.



**Analysis:** The conclusion we can draw from the above observations is that the net flux magnetic field produced by the bar magnet is 0, since the magnetic field has 0 divergence, and also the induced voltage across the coil is proportional to the velocity of the coil.

## 5 Precautions

- Handle the magnet with care. Do not allow it to fall on the floor or table-top.